

ASSEMBLY INSTRUCTION

	<p>1</p> <p>Put the screws in the holes, tight the screws, but not too tight, 90% is ok.</p>	<p>2</p> <p>Important please make sure the cam studs face out as shown</p>	<p>3</p> <p>Put the screws in the holes, tight the screws, but not too tight, 90% is ok.</p>
<p>4</p> <p>Then adjust the balance of the chair.</p>	<p>5</p> <p>Tight all the screws to 100%</p>	<p>6</p> <p>Stick the black part on the seat</p>	<p>7</p>

HARDWARE LIST

CODE	PARTS	QTY.
1	BACK	1
2	SEAT	1
3	FRONT LEG	2

HARDWARE LIST

CODE	PARTS	QTY.
A	M8X60 MM	1
B	M8x70MM	4
C	M8X80 MM	4
D	ALLEN KEY	1